



	ALUMINIUM <i>Aluminum</i>	H	A	B	C	D	STREFA WIATROWA <i>Wind zone</i>
Nr Kat. No. Cat. Typ Type	L30901 MU.10.AL	1000	-	-	-	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30951 MU.15.AL	1500	-	-	500	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30902 MU.20.AL	2000	-	500	500	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30952 MU.25.AL	2500	-	500	1000	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30903 MU.30.AL	3000	-	1000	1000	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30953 MU.35.AL	3500	-	1500	1000	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30904 MU.40.AL	4000	-	1500	1500	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30905 MU.50.AL	5000	1000	1500	1500	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30906 MU.60.AL	6000	2000	1500	1500	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30907 MU.70.AL	7000	3000	1500	1500	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m
	L30908 MU.80.AL	8000	4000	1500	1500	1000	I i III do 500 m, II do 150 m I & III to 500 m, II to 150 m

Maszt odgromowy (zwód pionowy) służy do przejścia bezpośredniego wyładowania piorunowego. Maszty lub zespół masztów tworzą wokół siebie (lub między sobą) odpowiednie strefy ochrony w zależności od przyjętej metody ochrony – kuli lub stożka. Przy rozmieszczaniu masztów istotne jest zapewnienie odpowiedniego odstępu izolacyjnego od chronionych urządzeń. Do masztu należy dobrać odpowiednie uchwyty w zależności od średnicy masztu i sposobu mocowania.

The lightning protection mast (air terminal) is used to intercept and discharge the lightning strike currents. The masts or a set of masts create appropriate protection zones around them (or between them), which can be defined by the method of a rolling sphere or protective angle. When planning the installation of masts, it is important to ensure the appropriate separation distance from the protected devices. Choose appropriate air rod holders for the mast, depending on the diameter of the mast and the method of mounting.

